



## GUANGDONG DETECTION CENTER OF MICROBIOLOGY

**REPORT FOR ANALYSIS** 

Report №.

2020FM04797R03E

Name of Sample

YKX300-Q3 Plasma Air Purifier

Applicant

Guilin Woodpecker Medical Instrument Co., Ltd.

**Test Type** 



Address: Building 66, No.100 Central Xian Lie Road, Guangzhou, China Postcode: 510070

Tel: +86 20 87137666

Fax : +86 20 87137668

Website : www.gddcm.com





#### GUANGDONG DETECTION CENTER OF MICROBIOLOGY

### REPORT FOR ANALYSIS



Report №.:2020FM04797R03E Verification Code: 28974351 Name of Sample YKX300-Q3 Plasma Air Purifier Test Type **Entrustment Test** Information Industrial Park, Guilin Woodpecker Medical GuiLin National High-Tech Zone, Applicant Address GuiLin, GuangXi, 541004, Instrument Co., Ltd. P.R.China Submitted for Testing by the One sample submitted Sample Source Sample Quantity Applicant

Spec and Lot № State and Machine YKX300-Q3 Plasma Air Purifier Characteristic of Sample **Test Completion** Sample Received 2020-03-19 2020-03-10 Date Date Test Standard and WS/T 648-2019 Appendix B Method Air disinfection field test Item Tested



The test data of the sample(s) is attached to the page(s) of this report.

Test Conclusion

 Issue Date:
 2000-04-20

 Remarks
 检验检测专用章

 Editor:
 Qiuwanchun

 Verifier:
 Sm Timin

 Approver:
 Yze Viubao





分析之前

### GUANGDONG DETECTION CENTER OF MICROBIOLOGY

Action time	The test organism	Serial Number	Total bacteria (cfu/m <sup>3</sup> )	Reduced rate (%)
OL OL OL O	0 (CK) Natural bacteria in air	1	1.5×10 <sup>3</sup>	
0 (CK)		2	$1.7 \times 10^3$	Lesting Lesting Lesting
		3 micro	1.5×10 <sup>3</sup>	So grido ghas grido
2h chico chico c	Natural bacteria in air		99	93.40
		2	1.1×10 <sup>2</sup>	93.53
		3	1.2×10 <sup>2</sup>	92.00

# ANALYSIS AND TEST RESULT

(Blank below)

Remarks

Method description: The prototype was turned on and switched to the maximum L4 gear for 2 hours in a 13m<sup>2</sup> test chamber, and then used six mesh impact type air microorganism sampler JWL-6 to sampling with air volume of 28.3 liters per minute. The sampling time of air was 5 minutes.





ショート 章

Report №.: 2020FM04797R03E

# Notice Items

- 1. The Test report is invalid if not affixed with Authorized Stamp of Test and Paging Seal.
- 2. The Test report is invalid without signature of verifier and approver.
- 3. The Test report is invalid if being supplemented, deleted or altered.
- 4. Without prior written permission, the report cannot be reproduced, except in full.
- Unless otherwise stated, the results shown in this test report refer only to the sample(s) submitted.
- Any dispute of the report must be raised to the testing body within 15 days after the report is received, exceeding which the dispute will not be accepted.
- 7. For the tested sample(s) submitted by the applicant, the sample information in the test report is provided by the applicant and the laboratory is not responsible for its authenticity.